



GPS setup check list.
Use BEFORE setting off
(for Garmin GPSmap 60)



Use the PAGE button to find the COMPASS page. Push the MENU button, then CALIBRATE COMPASS, then ENTR. Follow instructions on GPS



"new" Topo50 maps
 New Zealand TM
 WGS 84

"old" topo. maps
 New Zealand
 Geod Datm '49

1. Check TRACK LOG is turned ON
2. Log is CLEARED
3. Setup: Wrap When Full
 Record Method = Distance
 Interval = 0.01km (not 0.10km)
 (10m) (100m)
 Color: Choose what you want to show your "bread crumb" track

Track Log On Off

Select: Clear / ENTR / Yes

Wrap When Full (not)

Not Auto or Distance